

# MECCANO

Real Engineering in Miniature

#### MODEL-BUILDING WITH MECCANO

There is no limit to the number of models that can be built with Meccano—Cranes, Clocks, Motor Cars, Aeroplanes, Machine Tools, Locomotives—in fact everything that interests boys. A screwdriver and a spanner, both of which are provided in each Outfit, are the only tools necessary.

When you have built all the models illustrated in the Books of Instructions the fun is not over, it is just beginning. Now comes the chance to make use of your own ideas. First of all, re-build some of the models with small changes in construction that may occur to you; then try building models entirely of your own design. In doing this you will feel the real thrill of the engineer and the inventor.

#### HOW TO BUILD UP YOUR OUTFIT

Meccano is sold in 11 different Outfits, ranging from No. O to No. 10. Each Outfit can be converted into the next larger by the purchase of an Accessory Outfit. Thus Meccano No. O Outfit can be converted into No. 1 Outfit by adding to it a No. Oa Accessory Outfit. No. 1a Outfit would then convert it into a No. 2 and so on. In this way, no matter with which Outfit you begin, you can build it up by degrees until you have a No. 10 Outfit.

All Meccano parts are of the same high quality and finish, but the larger Outfits contain a greater quantity and variety, making possible the construction of more elaborate models.

#### THE "MECCANO MAGAZINE"

The "Meccano Magazine" is published specially for Meccano boys. Every month it describes and illustrates new Meccano models for Outfits of all sizes, and deals with suggestions from readers for new Meccano parts and for new methods of using the existing parts.

There are model-building competitions specially planned to give an equal chance to the owners of small and large Outfits. In addition, there are splendid articles on such subjects as Railways, Famous Engineers and Inventors, Electricity, Bridges, Cranes and Aeroplanes, and special sections dealing with the latest Engineering, Aviation, Motoring

and Shipping News. Other pages deal with Stamp Collecting, and Books of interest to boys; and a feature of outstanding popularity is the section devoted to short articles from readers.

If you are not already a reader write to the Editor for particulars. Supplies of the Magazine are very limited owing to the paper shortage.

#### THE MECCANO GUILD

Every owner of a Meccano Outfit should join the Meccano Guild. This is a world-wide organisation, started at the request of Meccano boys. Its primary object is to bring boys together and to make them feel that they are all members of a great brotherhood, each trying to help others to get the very best out of life. Its members are in constant touch with Headquarters, giving news of their activities and being guided in their hobbies and interests. Write for full particulars and an application form to the Secretary, Meccano Guild, Binns Road, Liverpool 13.

Clubs founded and established under the guidance of the Guild Secretary provide Meccano boys with opportunities of enjoying to the utmost the fun of model-building. Each has its Leader, Secretary, Treasurer and other officials. With the exception of the Leader, all the officials are boys, and as far as possible the proceedings of the clubs are conducted by boys.

#### MECCANO SERVICE

The service of Meccano does not end with selling an Outfit and a Book of Instructions. If ever you are in any difficulty with your models, or if you want advice on anything connected with this great hobby, write to us. We receive hundreds of interesting letters from boys in all parts of the world, and each of these is answered personally by one of our staff of experienced experts.

Whatever your problem may be, write to us about it. Do not hesitate. We shall be delighted to help you in any way possible.

This Dockside Crane can be built with Outfit No. 1.

# HOW TO BEGIN THE FUN


#### THE MOST FASCINATING OF ALL HORBIES

Meccano model-building is the most fascinating of all hobbies, because it never becomes dull. There is always something new to be done. First of all there is the fun of building a new model, and watching it take shape as part after part is added. Then, when the model is complete, comes the thrill of setting it to work just like the real structure it represents, by means of a Meccano Motor.

The following hints are given to show boys who are just starting the wonderful Meccano hobby how to get the greatest possible fun.

#### THE IMPORTANCE OF "LOCK-NUTTING"

In some models it is necessary to join certain parts together so that, although they cannot come apart, they are free to pivot or move in relation to one another. To do this the parts are bolted together as usual but the nut is not screwed up tightly, so that the parts are not gripped. Then, to prevent the nut from unscrewing, a second nut is screwed up tightly against it, the first nut being



A Flexible Plate used to form a curved surface.

held with a spanner. This method of using a second nut is known as Lock-nutting. In building models in which Rods revolve in the holes of other parts it is important to make sure that such holes are exactly in line with one another. This can be done by pushing through the holes a Drift, Part No. 36c, or a Rod, before the Bolts holding the various parts are tightened up.

A Rod is usually mounted in a support or bearing so that it is free to revolve. The Rod is then said to be lournalled in the Strip.

#### A FEW USEFUL HINTS

It will be noticed that with each model in this Book of Instructions is given a list of the parts required to build it. For the first few models it is a good plan to lay out on the table all the parts required for the one it is proposed to build, and put the remainder of the Outfit to one side. To help you to pick out the correct parts for your model a complete list of Meccano parts is given at the back of this Book, and all the principal parts are illustrated. In the list the parts are all numbered, and in most cases, their measurements are given. There is no need, however, to measure the parts to find out which is which, as the size is easily found from the number of holes. All Meccano holes are spaced \( \frac{1}{2} \) apart, so that by counting two holes to the inch the size of a part can be found at once. For instance, Part No. 2 is listed as a 5\" Perforated Strip, so you look in your Outfit for a Strip with eleven holes. Similarly No. 192 is a  $5\frac{1}{2}$ "× $1\frac{1}{2}$ "

Flexible Plate, so you look for a Flexible Plate eleven holes in length and three holes in width. By the time a few models have been built

the names of the parts will have become familiar.

Beginners sometimes wonder which section of a model should be built first. There cannot be any definite rule for this, as it depends on the design of the model. In stationary models the base usually should be built first. In most of the small models a 5½"×2½" Flanged Plate forms an important part of the structure, and often the best plan is to start building by bolting parts to this Plate. For other models a good general rule is that the sections that form supports for a number of other parts should be built first.

During the construction of a model it is best to screw up the nuts with the fingers, followed by a light turn with the screwdriver, leaving the final tightening until all the parts are connected up.

#### DRIVING YOUR MODELS

Models can be driven by means of either clockwork or electric motors.


Small and light models may be driven direct from the driving pulley of the motor or through a belt running over two pulleys of the same size, giving what is known as a 1:1 (one-to-one) ratio. For large models it is necessary to take the drive from a small pulley on the motor shaft to a larger pulley on the driving shaft of the model. In most cases a 1" Pulley on the motor shaft and a 3" Pulley on the model shaft will be found satisfactory. This provides a reduction ratio of approximately 3:1.

Rubber bands are very convenient for driving belts. Sometimes, however, a rubber band of the right length is not available, and then Meccano Cord or thin string is used. To tie the Cord to form an endless belt, use the familiar reef knot.

Flexible Plates are used for forming curved surfaces in models, but they are not intended to be bent at right angles. With careful handling a Plate can be bent to the required curve and after use straightened again.


All Outfits from No. 2 upward include a Cord Anchoring Spring, Part No. 176. This part provides a neat and positive method of fastening a length of Cord to a Rod. The Spring is pushed on to a Rod or Crank Handle, by turning it in such a way that its coils tend to unwind.

Ask your dealer for particulars of Meccano Clockwork and Electric Motors.



A Magic Motor fitted to drive a Steam Engine.


#### O.1 GARDEN SEAT




#### O.4 COUNTER SCALES

#### Parts required

1	of	No.	2	1 2	of	No.	22	1 1	of	No	. 52
2	,,		10	1	**	**	24	2	,,,	**	126
4	,,	**	12	9	*	**	37.	2	"	,,	126a
1			17	2		200	38	1			



#### O.2 FLAT TRUCK




#### Parts required

2	of	No.	5	1 2	of	No.	22	1 1	of	No.	90a
2	.,		12	8	17	.,	37	2		., *	126a
1			16	1	,,	**	52	2		*	142c

#### O.5 SCALES

#### Parts required

3	of	No.	2	2	of	No.	35	2	of	No.	126
1			1.7	10			37	2		,,	126
1			24	1			52				




# Parts required 4 of No. 2 2 ... 5 4 ... 12 1 ... 16 1 ... 19s 2 ... 22 1 ... 24 3 ... 35 18 ... 35 18 ... 37 1 ... 52 2 ... 90a


#### O.6 COSTER'S BARROW

2 " .. 126a


				Par	ts	requ	ired				
4	of	No.	2	1 2	of	No.	22	2	of	No.	90
2		**	5	16			37	2			126
2			10	1 2			48a	2			126
1			16	1	**	**	52	2	.,		142



#### · O.7 ACROBAT




#### O.8 MECHANICAL HAMMER




#### Parts required

3	of	No.	2	: 1	of	No.	17.	3	of	No.	35		1 0	No	111c
		,,,	5			***	19s	15	**	.,					126
		**					22				38	1 8	2 ,		126a
4	.,,	**	12	1	***	***	24	. 1	***	.11	52	1	1,	. ,,	142c


#### O.9 ELECTRIC TRUCK



#### O.10 ELEVATOR





# Parts required




#### O.12 BUCKING BRONCHO

The Bolts 1 are fitted with locknuts, so that the parts they attach are free to pivot. Bearings for a 2" Rod, the end of which is seen at 2, are provided by a Fishplare 3, bolted to an Angle Bracket 4, and a Trunnion 5.








# 1.2 DRILL


4	of	No.	2	1 4	of	No.	35
3	,,	,,	-5	20	,,	,,	37
8	,,	,,	12	4	,,	,,	38
1	,,	21	16	1	12.	,,	40
1	,,	,,	17	1	,,	,,,	52
1	,,	,,	195	2	,,	,,	126
4	,,	.,	22	1 2	,,	3)	126a

The drill table is made by bolting together two Flat Trunnions.

				1.3	SCAI
Pa	115	req	uired		
			. 2		
2	,,	,,	5		
2	,,	1:	4 77		· ·
2	**	**	22		3
1		,,	24		)
19		,,	37		1
1		"	38		/
1	.,	,,	40		
2		.,	48a		100
1		,,	52		/ 10
2	,,		90a		0
1	,,	.,	111c		1
2	,,	,,	126		W
2			126a		TO CO
1			155		69
2	,,		1.89		101

4 of No.






#### Parts required

4	of	No.	2	1.3	0	r No.	17	119	of	No.	31	1 2	of	No	90a	7	of I	Vo.	1265
4	,,	"	5	1 :	١.		2.2	4	**	"	37a	3	**	-	1116 125 126	+		**	155
3	,,	.,,	12		١,		24	2	.0		48a	1	.11	"	125	2	**	,,	189
2			16	. 1 . 3	2.	0.00	35	1		"	52	1 2	- 79	11	126				


#### 1.5 RACING SEAPLANE




#### Parts required

						*** -	cid.	211				
	3	of	No:	2	1	l of	No.	24	25	of	Vo.	111c
	3	**		3	11	9	***	37	- 2	,,		126
1	4	,,	,,	10		1 "	"	37a	1	,,		126a
	8			12		1 "	"	48a	2	"	. 12	189

#### 1.6 KIDDIE CAR



#### 1.7 SIDE TIPPING WAGON






Fig. 1.7a

Each of the Bolts 1 is lock-nutted. A piece of Cord is fastened to the Rod 2 (Fig. 1.7a) wrapped round it two or three times, and then is taken through the hole in the Flanged Plate above the Rod and secured to the Angle Bracket 3.


By turning the Bush Wheel the container is tipped sideways.

#### 1.8 STAMPING MILL


The anvil 1 is made up of two Trunnions bolted together. When the Crank Handle is rotated, the Fishplates bolted to the Bush Wheel strike the centre 1" Pulley on the hammer shaft and cause it to rise and fall.

#### Parts required

4	of	No.	2	1	3	of	No	. 37a
5	,,	"	5		2	,,	,,	38
4	,,	2.5	10		2	,,	**	48a
4	,,	,,	12	1	1	**	,,	52
1	**	,,	16		1	,,		90a
1	.,		19s		4			1110
4	"	,,	22	1	1			125
1	١,	.,	24		2			126
2	N	w	35		2			126a
24	,,	**	37		2	96		189



#### 1.9 LETTER BALANCE



Parts required

4 of No. 2

4 " " 5

4 " " 10

2 " " 12

1 " 16

2 " " 17

4 " " 22

1 " 24

4 " 35

24 " 37

4 " 38

2 " 48a

1 " 52

1 " 57c

1 " 90a

4 " 111c

1 " 125

2 " 126


2 " 126

2 " 126

2 " 126


2 " 155


2 " 189





The hoisting cord is secured to the Crank Handle, and then led over the ½" Bolt 1. It is then passed through the pulley block and fastened to the jib at 2. The jib is attached to the Bush Wheel 3 by means of Angle Brackets and the complete unit is pivoted as follows. A ½" Bolt is passed through the 5½"×2½" Fianged Plate from the underside, and is secured in the boss of the Bush Wheel by its set

#### 1.11 OPEN TRAMCAR


















#### 1.16 LIFTING BRIDGE





#### 1.18 MECHANICAL SWING


The left-hand 24" Strip that supports the swing is connected to the Crank Handle by passing the set screw of the 1" Pulley 2 through the hole in an Angle Bricket bolted to the Strip and then into the Boss of the Pulley. Bolt 1 on the Bush Wheel is fitted with lock-nuts

#### Parts required

			rai	1216	·qu	11 6	C		
4	of	No.	2	-		4	of	No	. 38
2		** **	5			1			40
2		**	10			2	**		48a
3			12			1	.,		52
1		**	16			1	,,	.,	111c
- 1	44		19s			1	,,		125
2			22			2	,,	ii.	126
1			24		5	2	,,		189
4	31	**	35		EX.	1-/	Ma	gic	Motor
15			37			1	Not	incl	uded in
2	,,		37a					Out	11)







#### 2.2 SPEED CAR

A 5½" × 2½" Flanged Plate, extended at the front by a 1½" radius Curved Plate and at the rear by two 2½" × 2½" Flexible Plates, forms the top of the car. The rear part of each side is formed by two 5½" Strips and a 2½" Strip, the former being connected together at the fail by Angle Brackets. Bolts 1 on each side hold a 2½" × ½" Double Angle Strip that carries the 1½" radius Curved Plate forming the underside of the front cowling.

#### Parts required

4	of	No.	2	1 4	of	No	22	1 1	of	No.	52	.1	2	of	No.	188
6			5	38			37	2		**	90a		2	.,,	**	189
2		**	10	1			37a	1		"	126		2			190
4			12	- 4		**	38	1 2		**	126a		2	,,	.,	200
2			16	2			48a	4			155	1				


#### 2.4 DRILLING MACHINE

The horizontal 2½" Strips at the top of the drill are joined together, and also to the vertical 2½" Strips, by means of Angle Brackets. The lower bearings 1 are two Angle Brackets bolted to a 2½" Strip, and the Rod forming the drill is journalled in these, and in a Fishplate at its upper end. A 2½"×2½" Flexible Plate is supported by a Double Angle Strip 2, and represents the table.


The drive is taken from the Motor to the 1° Pulley on the lower shaft. A second Driving Band passes round the ½° fixed Pulley supplied with the Motor, which is also fixed on the lower shaft, round the two Pulleys at 3, and finally round the 1° Pulley fastened on the vertical drill shaft.

#### Parts required

				,		1040						
2	of	No.	2	1	of	No.	24	1	of	N	5.111c	
5			5	4	11	1/	35	2	**	**	126	
1			10	22			37	2	**		126a	
5	**		12	2	**	144	37a	1			190	
1	,,	,,	16	1	100		40	1 A	1ag	ic	Motor	
2	,,	,,	17	1		*1	48a	(N	ot	ind	luded	
4			22	1	,		52	in	Ou	tfit	)	




#### 2.5 RAILWAY BREAKDOWN CRANE




Parts 4 of	req No.	uired 2 5 10 12 16 17 19g 22 24 35 37 37a 38 40 48a 52 57c 90a 111c 126 126a 155 176 187 188 189 190 200
6	4.	5
4 .,,	**	10
3 "	17	12
2 "		16
1	**	17
1 "	,,	19g
4 "	"	22
1		24
2		35
39 "		37
3 "	**	37a
3 "		38
1		40
2	.,	48a
1	,,	52
1		57c
2		90a
3		111c
2		126
2		126a
1 .	.,	155
1		176
1	45	187
1		188
2		189
1		190
2	**	200
- "	"	-

#### 2.6 FLOATING CRANE



#### RACING CAR



rec No
0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0

#### 2.8 BACON SLICER

The base of the model consists of a Flanged Plate fitted with four 24" Strips for legs. Two 54" x14" and two 24" x 14" Flexible Plates are bolted to the flanges of the Plate. The guides for the sliding carriage 4 are formed by two 54° Strips attached to the Flanged Plate by Angle Brackets


The carriage consists of a 2½ x 2½ " Flexible Plate 4 and is guided along the Strips by the Reversed Angle Bracket 1 and two Angle Brackets on the opposite side. The Angle Brackets are held in place by Bolts 5.

The cutting blade is represented by a Road Wheel fixed on a 3½ Rod journalled in two Flat Trunnions. A Pulley on this Rod is connected by a belt of Cord to a second Pulley on the Crank


The carriage is moved backwards and forwards by a crank consisting of a Bush Wheel 6 fixed on a 2" Rod. This Rod is journalled in the Flanged Plate and in the centre hole of a Double Angle Strip fixed across the interior of the base by Angle Strip fixed across the interior of the base by the Bolt 2 and another in a similar position on the opposite side. A 1" Pulley on the 2" Rod is connected by a crossed belt of Cord to a further 1" Pulley secured to the Crank Handle between the 54" Flexible Plates.

A guard for the rotating blade is provided by two Curved Strips attached to a 54" Strip 3. This Strip is fastened at one end to the Flanged Plate by a 24" Strip and a Fishplate 7, and at its

Plate by a 2½" Strip and a Fishplate 7, and at its other end it is attached to a 2½" × 2½" Flexible Plate bolted horizontally to the Flanged Plate.



#### 2.9 TRAMCAR




Two 55" × 12" Flexible Plates are curved and bolted across the ends of a Flanged Plate to form the driving compartments at each end, and a 44" x 24" Flexible Plate is used for one side of the model. This also is bolted to the Flanged Plate. The other side consists of two 14 radius Curved Plates, flattened and bolted in position Both sides are strengthened by a \$4" Strip, one of which is seen

The roof is supported on each side by three 24" Strips, connected at their upper ends by a 55" Strip. The roof is in halves, each half consisting of a 24"×12" and a 24"×24" Flexible Plate. The halves are joined at the centre by two Flat Trunnions, and the roof is secured to the Double Angle Strips 2 and Angle Brackets 3 on each side. A Crank Handle is used to represent the trolley pole and it is held in the Flat Trunnions and a Reversed Angle Bracket by Spring Clips:

The wheels are 1" Pulleys fixed on 33" Rods that run in holes in the sides of the model.

#### 2.10 PETROL-ENGINED STATION TRACTOR




Each side of the tractor unit consists of a 2½"×2½" Flexible Plate bolted to a Double Angle Strip 1. A 4½" × 2½" Flexible Plate is curved and attached to each side to form the top. The front and rear of the unit are each filled by a 24" x 14" Flexible Plate and a Flat Trunnion. The front axle is mounted in two Fishplates.

The load carrier is made by botting \$\frac{1}{2}\cdot \text{1}\frac{1}{2}\cdot Flexible Plates to the sides of a Flanged Plate. The rear axle is carried in two Curved Strips, which are attached to 24" Strips and secured to the Flunged Plate by Angle Brackets.

The tractor unit and the load carrier are connected by a Trunnion bolted to the tractor and a 2½" Strip 2 secured to the base of the load carrier. The 4" Bolt 3 is passed through holes in these parts and is fitted with lock-nuts.

## 2.12 BEAM ENGINE



The engine bed or base consists of two 5½"x1½" and two x1½" Flexible Plates bolted to the sides of a Flanged Plate. Two 55° Strips form the supports for the beam, which pivots on a 2" Rod held in position by Spring Clips.

The beam is made from two 5½° Strips held together by four Angle Brackets 1; which are bolted in pairs to form two U-shaped

The cylinder consists of two 2½" x ½" Double Angle Strips and two 2½" Strips. The piston rod is a 3½" Rod attached to the beam by an Angle Bracket, the Bolt 2 that holds the Bracket being lock-nutted. The Rod is held in the Angle Bracket by Spring Clips. The connecting rod is pivoted on a bolt lock-nutted to a Bush Wheel held on a 2" Rod journalled in a Trunnion and a Flat Trunnion. This Rod also carries a 1" Pulley and a Road Wheel. At its upper end the connecting rod is attached to the beam by the lock-nutted bolt 3.

The Magic Motor 4 is bolted to the base by its flanges, and its pulley is connected by a Driving Band to a 1" Pulley on the Crank Handle. A further 1" Pulley 5 on the Crank Handle is connected by a belt of Cord to the Pulley on the 2" Rod.

#### 2.11 MECHANICAL HACKSAW

The base consists of Flexible Plates bolted to a Flanged Plate. One side is formed by a  $4\frac{1}{2}^{\circ} \times 2\frac{1}{2}^{\circ}$  and a  $2\frac{1}{2}^{\circ} \times 1\frac{1}{2}^{\circ}$  Flexible Plate, and the other by two  $5\frac{1}{2}^{\circ} \times 1\frac{1}{2}^{\circ}$  Plates. A  $2\frac{1}{2}^{\circ} \times 2\frac{1}{2}^{\circ}$  Flexible Plate is bolted to each end. The base is strengthened at each end by Double Angle Strips 1 and a  $5\frac{1}{2}^{\circ}$  Strip on each side.


The saw is actuated by a crank formed from a Bush Wheel fixed to a 34" Rod. The Rod rotates in a Trunnion and a Flat Trunnion. The Trunnion is raised from the Flanged Plate by

two Washers: The Rod carries a 1" Pulley 2 and a Road Wheel. The Pulley 2 is connected by a belt of Cord to a similar Pulley fixed on the Crank Handle.

The material to be sawn is clamped to the base by means of two 24" Strips. one of which is shown at 3.

#### Parts required

3	of	No.	2	1	1	of	No.	40
6	.,,		5		2	**		48a
2 2 1	,	41	12		1.	,,		52
2		,,	16		4	,,	**	111c
1		**	19g		1	3.5	31.	126
3	"	**	22		1	13	22	126a
1	**		24		1	**	"	187
30 8	,,	**	37		1	**	**	188
8	**	**	37a		2	**		189
4	"	"	38	J	2			190
			1 01 1	10.	19	1		



Parts required

12 16 17

22 35 37

37a

48a

52

90a

111c

125 126

126a

155


190

191

38

#### 2.13 TRAVELLING CRANE


A 2" Rod is secured in the boss of the Bush Wheel 3. It then passes through the Road Wheel and through the centre of a 2½" × ½" Double Angle Strip bolted between the two Trunnions 1. A Washer and a Cord Anchoring Spring are pushed on to the Rod to hold it in position. The crane jib is attached to the Bush Wheel by the Angle Brackets 2.



#### Parts required

						1.0	11 12 11	cqui	1 00						
4	of	No.	2	1 4	of	No.	22	2	of	No.	48a	1	of	No.	176
6	**	"	5	1		"	24	1	"	,,	52	1	"	**	187
4			10	4	**		35	1	"	**	57c	2	**	"	188
6	**		12	38	**	**	37	2	**	**	90a	2		,,	189
2			16	2	**	**	3/a	2	**	20	111c	1	33	25	200
4		**	10-	3	**	"	38	2	"	"	126				
1	**	**	19g	1	**	**	40	2	**	**	126a				


#### 2.14 LAWN MOWER




#### 2.15 LUMBER TRUCK AND HORSE

A Magic Motor is mounted beneath the carr, and the Driving-Band is taken from the pulley on the Motor to a ½" fixed Pulley (supplied with the Motor); fastened on the 3½" Rod that forms the front axle.

The forelegs of the horse are neld together by means of two Angle Brackets bolted in the positions shown. This construction is duplicated at 1 for the hind-legs. The forelegs of the horse are held clear of the ground by the reins.



#### 2.16 PUNCHING MACHINE



The base consists of a Flanged Plate, which is edged with two  $5\frac{1}{2}"\times1\frac{1}{2}"$  and one  $2\frac{1}{2}"\times1\frac{1}{2}"$  Flexible Plates. The  $5\frac{1}{2}"\times1\frac{1}{2}"$  Plates are braced together by the Double Angle Strips 1 at each end.


An upright column is formed from two 5½" Strips fastened to two Trunnions attached to the base. They are joined at their upper ends by two Angle Brackets fixed together to form a U-shaped piece. A ½" radius Curved Plate is attached to the column at the top by a 2½" Strip 2 and at its lower end by two Fishplates. The punch rod passes through bales in 74" suite Strip.


at the top by a 24° Strip 2 and at its lower end by two Fishplates. The punch rod passes through holes in 24° guide Strips 3.

Strips 2, one at each side of the machine, provide supports for two Flat Trunnions that carry a rocker arm. This is formed by two 24° Strips overlapped three holes, and it is pivoted on a 2° Rod held in the Flat Trunnions. One end of the arm is connected by an Angle Bracket to a 34° Rod representing the punching tool. The Rod is held in a hole of the Angle Bracket by means of a Spring Clip and a Cord Anchoring Spring 6. The rear end of the arm is connected to the foot-operated lever 4 by a 54° Strip. The lever is weighted by four 1° Pulleys fixed on a 2° Rod.

The Bolts 5 seen at different points of the model are each enutted.

The punching table is formed by a Bush Wheel bolted to a  $24^{\circ} \times 14^{\circ}$  Flexible Plate attached to the column by a Fishplate and Angle Bracket





#### 2.18 LETTER BALANCE

Each side of the model consists of a 5\frac{1}{2}" \times 1\frac{1}{2}" Flexible Plate and two 5\frac{1}{2}" Strips. These are connected at the top by two Double Angle Strips. A 24" Strip 3 is attached by Fishplates to one of the Double Angle Strips.

Two 21" x 21" Flexible Plates 1 are overlapped three holes and attached to the sides by Angle Brackets. The 24" × 14" Flexible Plate 2 is secured to the Double Angle Strip by an Angle Bracket. The sides and front are fastened to the base by Angle Brackets and

The pointer consists of a 2½° Strip and a Flat Trunnion and is clamped between two 1° Pulleys fitted with Rubber Rings. These Pulleys are locked on a 3½° Rod journalled in the 2½° Strips 4 and 6.


An Angle Bracket 5 is fastened to the 2" Rod by a Spring fland 5.

An Angle Bracket 5 is fastened to the 2" Rod by a Spring Clip
and a Cord Anchoring Spring. This Angle Bracket is connected to a
Bush Wheel 7 by two 2½" Strips bolted together. The Bush Wheel
is loose on a Rod 8 as shown. A length of Cord from the connecting
strip is passed several times around the Rod litted with the pointer. It is then passed through a Driving Band looped around the Rod 8 and tied to the Strip 4.

An indicator dial is marked on a piece of cardboard, which is then bolted in position at the front of the model.

#### Parts required

				1 14	100	,	1011100				
1	of	No.	2	1 32	of.	No.	37	1 1	of	No.	126
Ś	.,	"	5	4	,,		37a	1	**	**	126
2		10	10	4	**		38	2	,,	**	155
3		**	12	1	99	**	40	1	,,	**	176
2	,,		16	2	*	147	48a	1	,,,	2.7	186
1	**		17	1	**		52	1	10	**	187
2		**	22	2		**	90a	1	,,	10	188
1	**		24	2	**	,,	111c	2	**	,,	189
ŧ	*		35	1	37	"	125	2	,,	"	190



The Gord 1 is wound round the Crank Handle about 12 times, then one end of it is fastened to a Small Loaded Hook and the other end to the Cord on the


bucket.

A Curved Strip is pivoted by a 2" Bolt through one of its ends in the position of Bolt 2 but on the rear side of the model. A 1" Pulley is attached with a 3" Bolt to the other end of the Curved Strip to not as a weight. A loop of Cord is fastened through the slotted hole next to the bottom of the Strip, and then passes round the 1" Pulley 3 on the shaft of the Bush Wheel, to act as a brake band. The Cord should be long enough to allow the Strip to lie nearly horizontal. luffing cords are attached to two 24" Strips lock-nutted to the lib.

## 2.19 DRAGLINE EXCAVATOR

#### Parts required

						1:2	11 13 1	od.		-0					
4	of	No.	2	11	of	No.	40	2	of	No.	111c	2	of	No.	188
6	,,	**	5	1	,,	**	48a	2	99	0.	126	2	,,		189
2	**	,,	10	1	.,	.,	52	2	:11		126a	2	,,,		190
8	**	,,	12	1		100	57c	1	,,	**	176	1			199
1	,,	,,	16	2	e.		90a	1	**	**	187	2	"		200
2		.,	17												
1	,,		19g								-	200			
3	.00	,,	22			AT	(40)	V		0				-	
1	,,		24			A	05	0	0	6	.5 \$	6		THE REAL PROPERTY.	
4	,,		35				~	*		L		-	0	()	20
40	v	**	37					1	\			_			
4	,,		37a							/	1	D	S.	1	5
1	,,		38	•							10		7.0		00
												4	P		16
													,	1	
															40



#### 2.20 WINDMILL


	-			************				_	
159	rts	req	uired			ISN.		<u></u>	
4	CI	No.	2		A	0.0000000000000000000000000000000000000	15 NA 638	Van	
6 8	.,	**	5		A A				
8		**	2 5 12	4	4 //	1,00		11.4	
1		**	16		10			4 9 6	
1			190			A STATE OF THE PARTY OF THE PAR	BOTOS PET HATE	U	
4	ke .		22		1500	1	/	000	
1			22° 24 35			000	e #		1
2	**	**	25		V 10	199 (3)	MYC		)
	1.0	**	37	7 —	_				
32	**	**	37	5	0	30		0/	
3	**		38		1	STATE OF THE PARTY.	0		
1	**		40						
2	**	**	48a		45.7		0 0		
1		**	52						
2		**	90a						
2			126		HANNE OF		SE /2		
2	**		126a		OD	17/10/200	68 C		
2			155				Dille	TO	-2
2		**	188		101			(12)	-
2	**	**	189		1869	1/12/1	10	間	
2	**	**	107		101	1993	1 15	1 12	
4	**	**	190		(M)	(IDA)	1 1	1	
1	**	**	199					11/11	
2	**		200			Fig. 2.2	Da		

Four S4" Strips boiled to the Flanged Plate forming the base are connected at their upper ends by Double Angle Strips 1 and 24" Strips 2. A  $24" \times 14"$  Flexible Plate is boilted at each side, and the front and rear walls consist of  $24" \times 24"$  Flexible Plates. These Plates are connected together by 24" Strips 3 attached by Angle


The mill roof is formed by two 1\(\frac{1}{4}\) radius Curved Plates, and is attached by two Angle Brackets to a Curved Strip bolted to each 2\(\frac{1}{2}\) x 2\(\frac{1}{2}\) Flexible Plate. The 3," radius Curved Plate 4 is secured by Angle Brackets 5 to two Flat Trunnions bolted to the Curved Strips.

The sails are \$\frac{1}{2} \times 1\frac{1}{2} \times \frac{1}{2} \times 1 \frac{1}{2} \times \frac{1}{2} \t Plates so as to grip them securely. The Pulley and Bush Wheel are locked on a 3½" Rod journalled in the 2½" x 2½" Flexible Plates. A 1" Pulley on this Rod is connected by a belt of Cord to a similar Pulley on the Crank Handle.


#### 2.21 AUTOGIRO








#### 2.22 MOBILE CONCRETE MIXER




The model is built up on a Flanged Plate. The front axle is journalled in a Double Angle Strip lock-nutted to a Trunnion bolted to the Plate. The rear axle runs in two Curved Strips. The rotating drum is made by bending two 5½" x1½" Flexible Plates around a Road Wheel and a Double Angle Strip 1. The Road Wheel is locked on a 2" Rod journalled in the centre hole of a compound strip and a Reversed Angle Bracket 6. The compound strip consists of two 2½" Strips overlapped three holes, and an Angle Bracket is bolted to: each end. One Angle Bracket is lock-nutted to the top hole of a 2½" Strip 2 and a 2½" x1½" Flexible Plate forming part of the strip of the strip and a constant of the strip and a co

the engine housing. The Strip 2 is attached to the base by a Trunnion.


The front support for the drum is provided by a Flat Trunnion attached to an Angle Bracket 3, and passes through the Trunnion. A Bush Wheel is locked to the shank of the Bolt and is used for tipping the contents of the drum into the dis-



#### 2.23 HORSE AND TIPPING CART



#### 2.24 ELECTRIC DELIVERY VAN



The Curved Strips and the  $1\frac{14}{16}$  radius Curved Plate forming the front of the model are bolted to a Flanged Plate by means of Bolts 1 at each side of the model. The upper end of the Curved Strips support a  $5\frac{1}{2}$  Strip, a  $5\frac{1}{2} \times 1\frac{1}{2}$  Flexible Plate, and a  $2\frac{1}{2}$  Strip 2. The Strips 2 are connected by a Double Angle Strip; to which is bolted a  $4\frac{1}{2} \times 2\frac{1}{2}$  Flexible Plate forming cart of the roof.


Part of each side of the model is filled in by a 2½" × 2½" Flexible Plate 3 and a 2½" × 1½" Flexible Plate 4. The tail is formed by a ¾" radius Curved Plate attached to Trunnions 5, and this is joined to the roof by a 1½" radius Curved Plate 6.

The rear axle is a 3½" Rod mounted in two Fishplates. A ½" Pulley on this Rod is connected by a Driving Band to a Magic Motor bolted underneath the Flanged Plate-The front axle is mounted in two Fishplates bolted to the Curved Strips.

The steering wheel is represented by a Bush Wheel, which is fattened to an Angle Bracket by a 1" Bolt, the Angle Bracket being secured to the Double Angle Strip 7.

#### 2.25 GAS ENGINE.

				Par	ts	requ	uired				
3	of	No.	5 1	33	of	No.	37	1	of	No.	126a
4		**	10	3	.,	**	37a	1	10		155
8		**	12	4		*1	38	1		**	176
2	.,	**	16	1	.,	**	40	1	,		187
1		**	17	2	.,		48a	2		1	188
1		**	19g	1			52	2		**	189
4			22	1	,,		111c	1			190
1			24	1			125	2	,,	**	200
4			35	1			126				



The bearings for the Rod representing the crankshaft are a Flat Trunnion and a Trunnion. The crankshaft carries a Road Wheel and a 1° Pulley at one end, a second 1° Pulley between the bearings, and a Bush Wheel at its other end.


The connecting rod is fistened to the Bush Wheel and to an Angle Bracket 3 by lock-nutted Bolts 1. The Rod 2 is held in the Angle Bracket 3 by Spring Clips, one on each side of it. An Angle Bracket 4, carrying a Fishplate, is bolted inside the cylinder, and a similar arrangement is fitted at the other end. These form bearings for the Rod 2.


The model is operated by the Crañk Handle, which carries also a 1° Pulley connected to one of the 1° Pulleys on the crankshift by a bott of Cord. A second Cord drives the governor, which is mounted on a 33° Rod journalled in the 54° × 24° Flanged Plate and a Reversed Angle Bracket.




When you have built all the models shown in this Book of Instructions, you will be keen to build bigger and more elaborate models. Your next step is to purchase a Meccano No. 2a Accessory Outfit containing all the parts required to convert your No. 2 into a No. 3 Outfit. You will then be able to build the full range of No. 3 Outfit models, a selection of which is illustrated on this page.

If you prefer to do so, you can build up and develop your Outfit quite easily by adding various parts to it from time to time. The model-building possibilities of the Meccano System are unlimited, and the more Meccano parts you have the bigger and better the models you will be able to build








Here are a few simple and interesting movements showing how easily real mechanisms can be reproduced with Meccano.


#### USEFUL BAND BRAKE



S.M.111. The brake lever consists of a 3½° Strip 1, pivotally attached at a suitable point on the frame of the model, to be fitted, by means of a lock-nutted ½° Bolt 2. The driven shaft 4 is fitted at one end with a 1° fast Pulley 3 round which a short length of cord is passed. The two ends of this Cord are secured to the brake lever at the points shown in the illustration.


If increased braking effect is desired a larger Pulley may be used in place of the 1" fast Pulley 3, the brake later 1 being attached in a lower position if necessary. Alternatively a weight can be hung from the end of the brake lever.

#### BUILT UP ROLLER BEARING



S.M.136. The spider frame is built up from Double Bent Strips 1 connected together by two Double Brackets 2. The four wheels used are represented by 4" loose Pulleys journalled on Pivot Bolts secured to the outer ends of the four arms of the frame. Four Washers, two on each side of the Pulleys are passed on to the shank of each of the Pivot Bolts that are attached to the Double Brackets 2. In the case of the other two Pivot Bolts, two Washers are placed against the external side only of the Pulley.

#### SIMPLE STEERING GEAR




S.M.162. The simple steering gear will be found suitable for most small model vehicles.

In this example the two front wheels are mounted on separate stub axles that are secured to each end of a rigid front axle. The base of the chassis consists of two long Angle Girders connected together at the front end by a  $3\frac{1}{2}$ " Angle Girder and filled in along their length by means of  $5\frac{1}{2}$ "  $\times 3\frac{1}{2}$ " Flat Plates.


The front axle, a  $3\frac{1}{2}'' \times \frac{1}{2}''$  Double Angle Strip, is pivotally mounted at its centre on a Bush Wheel and short Rod. It is fitted,  $\frac{1}{2}''$  fron each end, with a  $\frac{1}{2}'' \times \frac{1}{2}''$  Angle Bracket, this forming the inner bearing for its respective stub axle. The outer bearing for the axle consists of the upturned lug of the Double Angle Strip. One end of this latter part is fitted with a pivotally attached  $4\frac{1}{2}''$  Strip, by means of which the front axle is linked up to a Crank fixed to the steering column.

#### SAFETY CATCH FOR CRANE WINDING GEAR

S.M.125. The Compression Spring 3 is mounted on the Crank Handle 1 between the Collar 4 and a Washer, and normally holds the Collar 2 against the inner side of the plate. The Collar 2 is fitted with a  $\frac{2}{8}$ " Bolt, and if the Crank Handle commences to rotate, the head of this Bolt strikes against the stop 5 and prevents further movement.




#### BRAKE LEVER and QUADRANT



S.M.112. This mechanism is a form of band brake in which the lever 1 can be held in any position by means of the quadrant 2. In this way varying pressures can be applied to the Pulley forming the brake drum.

One end of the brake Cord is attached to a  $\frac{1}{2}$ "  $\times \frac{1}{2}$ " Angle Bracket bolted in a suitable position on the model. After passing round the 1" fast Pulley forming the brake drum the Cord is secured at the next to bottom hole of a 3" Strip 1. This Strip forms the brake lever, and it is secured to the frame of the model by a lock-nutted Bolt.

### MECCANO PARTS



# MECCANO PARTS

# 09933990 120° 120b. Compression Spring, &" long 122. Miniature Loaded Sack Cone Pulley, 1;", 1" and ?" diam. Reversed Angle Bracket, 1" 175. 0 0 0 OOD. 126\* 126a. Plat Trunnion Trunnion 128 Bell Crank Bell Crank, with Boss 129. Toothed Segment, 15" radius





Eccentric, Triple Throw, 1". 2" and 4" Eccentric, Single Throw, 4"





Dredger Bucket Flywheel, 21" diam.





Corner Bracket, 1; 133a





1364

Handrail Support 136a. Handrail Coupling 137. Wheel Flange



138a Ship Funnel



139. Flanged Bracket (right) 1393



Universal Coupling





Rubber Ring (to fit 3" diam. rim) Motor Tyre (to fit 2" diam. rim) 1420. 142b. 142c. 142d.




143. Circular Girder, 54" diam.



144. Dog Clutch





Circular Strip, 74" dlam, overall 146. 146a.



Pawl, with Pivot Bolt and Nuts 147a. Pawl Pivot Bolts with 2 Nuts 1476.

147c. Pawl without boss Ratchet Wheel 148.



Pulley Black, Single Sheave Two 153. Three



154a. Corner Angle Bracket, ‡\* (right-hand) 154b. Corner Angle Bracket, ‡\* (left-hànd) 155. Rubber Ring (for 1\* Pulleys)



157. Fan, 2" diam.





Channel Bearing, 14"×1"× 5" Girder Bracket, 2"×1"× 5" 161.







162 Boiler, complete, 5" long × 2 ½" diam.

Ends, 2½" diam. × 3"

without ends, 4½" long × 2½" diam.


Sleeve Piece, 1½" long × ½" diam.

Chimney Adaptor, 3" diam. × ½" high 163.






Swivel Bearing 166. End 167b. Flanged Ring, 9;" diam.



Ball Bearing, 4" diam. ... Race, flanged disc, 31" diam. 1683 ... toothed .. 4" diam. ... Cage, 32" diam., complete with



171. Socket Coupling



175. Flexible Coupling Unit



176. Anchoring Spring for Cord







Rod Socket Gear Ring, 34" diam. (133 ext. teeth,






Steering Wheel, 11 diam. Driving Band, 25 (Light) 185. 1863. 10" 186b. 10" (Heavy) 1865. 186d. 15" 187. Road Wheel, 24" diam. 187a. Conical Disc, 11" diam.







200 198. Hinged Flat Plate, 44" × 24" 199. Curved Plate, U-Section

24" × 24" × 4" radius 24" × 24" × 1 11" radius



2114 & 211

211a. Helical Gear, 1 Can only be 211b. .. . . 11 used together used together



Rod and Strip Connector



214 Semi-Circular Plate, 24"





216 Cylinder, 24" long, 11" diam